

# Kitchen Roll Holder 2.0




## Table of contents

|                                   |   |
|-----------------------------------|---|
| Quick guide                       | 2 |
| Scope of delivery                 | 3 |
| General information               | 3 |
| Safety                            | 4 |
| Installation                      | 5 |
| Resistance of the unrolling brake | 6 |
| Technical data                    | 6 |
| Customer service                  | 7 |


## Quick guide

1



Fasten the holder to the base plate using the three larger screws. Make sure that the countersinks of the holes face upwards.

2




Attach the unrolling brake to the holder using the two smaller screws. Stick the silicone sticker onto the brake and press it on firmly for 30 seconds.

3a




**For adhesive mounting:** Thoroughly clean the surface and the base plate of the holder with a dry cloth.

4a




Press the holder on firmly for **30 seconds** and wait **24 hours** before use.

3b



**For rough surfaces,** mount the holder using screws (optionally with wall plugs) and the screw covers.


5



If you ever have a question or a problem with the product, please get in touch with us. We will surely find a suitable solution for you.

### Adhesive mounting possible:


You can mount the kitchen roll holder with the enclosed 3M tape on the following surfaces:




Stone



Glass



Wood




all smooth surfaces

### Adhesive mounting not possible:

The kitchen roll holder cannot be glued to the following surfaces, as the adhesive would not stick:



Plaster



Textured stone



Wallpaper



all textured surfaces

## Scope of delivery

- 1 x Kitchen roll holder
- 1 x Unrolling brake
- 1 x Base plate
- 4 x Screws for attaching the holder to the base plate (1 spare screw)
- 3 x Screws for attaching the unrolling brake to the holder (1 spare screw)
- 1 x Double-sided adhesive tape for mounting the kitchen roll holder
- 2 x Wall plugs for mounting
- 4 x Screws for mounting (2 x long, 2 x short)
- 2 x Screw covers
- 1 x Silicone sticker for the unrolling brake
- 1 x Accompanying card

## General information



*Read the operating instructions.*

This instruction manual belongs to the kitchen roll holder from WOHNHELD.

It contains important information on commissioning and handling. Failure to observe these operating instructions may result in damage to the product.

## Explanation of symbols

The following symbols and signal words are used in these operating instructions.

**NOTE** - This signal word warns of possible damage to property.



This symbol gives you useful additional information on operation or handling.



Regulation (EC) No. 1907/2006 (REACH Regulation) is an EU chemicals regulation that came into force on June 1, 2007. REACH stands for Registration, Evaluation, Authorization and Restriction of Chemicals. As an EU regulation, REACH is equally and directly applicable in all member states.

## Copyrights

Passing on and copying of this document, utilization and communication of its contents are prohibited unless expressly permitted. Violations oblige the offender to pay compensation. All rights reserved in the case of patent or utility model registration.

---

# Safety

## Intended use

The kitchen roll holder is designed exclusively for unrolling kitchen rolls.

Use the kitchen roll holder only as described in this manual. Any other use is considered improper and can lead to property damage. The kitchen roll holder is not a child's toy.

The manufacturer or distributor accepts no liability for damage caused by improper or incorrect use.

## Safety instructions



**NOTE:** Bend the unrolling brake only very gently and only a little – bending it too far can cause it to break.

# Installation

## Assembling the kitchen roll holder



### **NOTE** on assembling the kitchen roll holder:

- Open the packaging and remove the kitchen roll holder along with the included accessories.
- Attach the holder to the base plate using the three larger screws and the included L-shaped Phillips key. (A total of 4 large screws are included – 1 is a spare.)
- Next, fasten the unrolling brake to the holder using the two smaller screws. (A total of 3 small screws are included – 1 is a spare.)
- If desired, you can attach the included silicone sticker to the front end of the unrolling brake. This makes the brake softer, slightly increases the roll-off resistance, and reduces noise.

## Mounting with double-sided adhesive tape:



**NOTE:** Use the double-sided adhesive tape for mounting only on smooth surfaces (e.g., smooth wood, glass, metal, most plastics, stone, and tiles).

**NOTE:** If you need a new 3M tape for installation, feel free to contact us at [info@wohnheld.eu](mailto:info@wohnheld.eu). We will gladly send you a new one free of charge.

- Choose a suitable location with a smooth surface.
- Thoroughly clean the area on the kitchen roll holder where the double-sided adhesive tape will be applied using a dry cloth.
- Remove the protective film from one side of the double-sided adhesive tape.
- Stick the adhesive tape onto the kitchen roll holder with the sticky side.
- Remove the second protective film from the adhesive tape.
- Press the kitchen roll holder firmly onto the surface for 30 seconds.
- Wait 24 hours to allow the full adhesive strength of the 3M tape to develop.
- The kitchen roll holder is now ready for use.

### Mounting with screws:



#### NOTE on mounting with screws:

- Choose a location where you can screw in the kitchen roll holder.
- Position the kitchen roll holder at the desired spot and fasten it with the two screws.
- Take the two screw covers and screw them onto the screw heads.
- The kitchen roll holder is now ready for use.

### Mounting with wall plugs and screws:

- Choose a location where you can drill holes for the wall plugs.
- Hold the kitchen roll holder in place and mark the two drill holes for the wall plugs with a pencil.
- Using a drill (diameter: 6 mm), drill two holes for the wall plugs.
- Insert the wall plugs fully into the holes.
- Take the two screws and fasten the kitchen roll holder using the wall plugs.
- Take the two screw covers and screw them onto the screw heads.
- The kitchen roll holder is now ready for use.

## Resistance of the unrolling brake

If you find the resistance too low or too high, you can **gently** bend the unrolling brake down or up.

(But please make sure that you do not tear the unrolling brake off the holder.)

You can view a video tutorial on this at [www.wohnheld.services](http://www.wohnheld.services).

## Technical data

|               |                        |
|---------------|------------------------|
| Model:        | Kitchen roll holder    |
| Device color: | silver, black or white |
| Weight:       | approx. 150 g          |
| Size:         | 310 x 150 x 45 mm      |

Subject to technical and optical changes.

---

## Customer service / Customer support

Dear customer,

Our customer support staff will be happy to assist you. Please submit your concerns to:

[info@wohnheld.eu](mailto:info@wohnheld.eu)

With kind regards

Your team from WOHNHELD